How to record Edimax IP Camera to a NAS server

Introduction

You can use Edimax IPCam Surveillance Software to record video on a NAS (Network attached storage).

Symptom

The error message "The parameter is incorrect".



Solutions

Step 1. Map a network drive for the NAS device.



🌀 🔏 Map Network Drive	3. Click on Browse and select your NAS device	×
What network folder v Specify the drive letter for the Drive: Folder: Example: \\serv. Reconnect as Connect to a W	vould you like to map? e connection and the folder that you want to connect to:	
	<u> </u>	cel

Step 2.	Launch the IPCam Surveillance Software from	your	Start ->	All Programs	->
Internet	t Camera list				



Step 3. In the IPCam Surveillance, click on Setup -> General Options.



Step 4. In the window of "General Options", click on Browse and select the mapped drive Z:

General EMaid Setting Security About Dectory Information Data Dree Forows for Folder Environe Free Recor Image: Benyle Bin	General Options				X
Dectory Information Deta Dree Browse for Folder Fires Reco General Set Max Vdee Son Tare Def Dorby Christ (A) Def Dorby Christ (A) Def Dorby Christ (A) Def Dorby Christ (A) Def Other (C) Def Dorby Christ (A) Def (Wave) (Z) Concel OK Cancel OK Cancel Central Options Central Options Central Settings Max Vdeo File Size Second (B) Cycle Recording Security About Directory Information You must use a subfolder Data Directory ZUPCamera Fires Recording Security About Central Settings Max Vdeo File Size Second (B) Cycle Recording Deable OK Cancel	General E-Mail S	etting Security About			
Data Dree Browse for Folder Free Recc In Activorits In Activorits In Activorits In Activorits <td>Directory Inf</td> <td>ormation</td> <td></td> <td></td> <td></td>	Directory Inf	ormation			
Free Recc General Sett Max Vide Image: Security Production Concol Dive (6:) Image: Security Production Concel	Data Dire	Browse for Folder			Browse
General Sate General Sate Max Vdec Scan Time Concel Sate Concel Sate Concel Sate Concel Sate Concel Conc	Free Reco	Network			
Max Vdec Image: Control Panel Image: Control Panel	General Sett	 Libraries Recycle Bin 			
Scan Time Cycle Res Cycle Res Cycle Res Cycle Res Ceneral Options Ceneral Options Ceneral Setting Security About Directory Information Prou must use a subfolder Directory Information Directory Z:\PCamera Rrowse Free Recording Space Scan Time Scan Ti	Max Video	 Image: Book of the second secon	L	E	
Cycle Rec P G DUrve (E) Q DUrve (E) Q Durve (E) Q Durve (E) Pour must use a subfolder Durve (E) Q Durve (E) General Settings MB G Q Durve (E) Q Durve (E) Q Q Durve (E) <td< td=""><td>Scan Tim</td><td> Floppy Di Evolution Evolution </td><td>isk Drive (A:) < (C:)</td><td></td><td></td></td<>	Scan Tim	 Floppy Di Evolution Evolution 	isk Drive (A:) < (C:)		
OK Cancel Orectory Ceneral Options Ceneral Options Image: Ceneral E-Mail Setting Security About. Directory Information You must use a subfolder Data Directory Z:\PCamera Browse Free Recording Space Free Recording Space 54095 Max Video File Size So MB Scan Time S second(s) Cycle Recording Disable	Cycle Red	▷ ♣ DVD RW ▷ ♣ CD Drive ▷ ♀ e (\\Vsav	(E:) (e) (Z:)	-	
OK Cancel General Options Image: Constant of the second secon			ОК	Cancel	
OK Cancel General Options Image: Construct of the second seco					
OK Cancel General Options Cancel Ceneral E-Mail Setting Security About Directory Information Directory Information You must use a subfolder Data Directory Z:\IPCamera Browse Free Recording Space Free Recording Space 54095 Max Video File Size 50 Scan Time 3 Scan Time 3 Ocycle Recording Disable					
OK Cancel General Options Image: Concel Security About Directory Information You must use a subfolder Data Directory Z:\PCamera Browse Free Recording Space Free Recording Space 54095 Max Video File Size 50 Scan Time 3 Que Recording Disable					
General Options					
General E-Mail Setting Security About Directory Information You must use a subfolder Data Directory Z.\IPCamera Browse Free Recording Space 54095 MB General Settings Max Video File Size So MB Scan Time 3 • second(s) Cycle Recording Disable • Image: Second file				OK	Lance
Directory Information You must use a subfolder Data Directory Z:\PCamera Browse Free Recording Space 54095 MB General Settings Max Video File Size 50 MB Scan Time 3 second(s) Cycle Recording Disable •	General Options			Ok	
Data Directory Z'\IPCamera Free Recording Space 54095 Max Video File Size 50 Max Video File Size 50 Scan Time 3 Scan Time 3 Cycle Recording Disable	General Options General E-Mail	Setting Security About		ок 	
Free Recording Space 54095 MB General Settings Max Video File Size 50 • MB Scan Time 3 • second(s) Cycle Recording Disable •	General Options General E-Mail	Setting Security About	You must use a s	ubfolder	
General Settings Max Video File Size 50 V MB Scan Time 3 Second(s) Cycle Recording Disable V	General Options General E-Mail Directory In Data Dire	Setting Security About	You must use a s Z:\IPCamera	ubfolder	Browse
Max Video File Size 50 V MB Scan Time 3 Second(s) Cycle Recording Disable V	General Options General E-Mail Directory In Data Dire Free Rec	Setting Security About cormation ctory ording Space	You must use a s Z:\IPCamera 54095	ubfolder MB	Browse
Scan Time 3 v second(s) Cycle Recording Disable v	General Options General E-Mail : Directory In Data Dire Free Rec General Set	Setting Security About comation ctory ording Space	You must use a s Z:\IPCamera 54095	ubfolder MB	Browse
Cycle Recording	General Options General E-Mail : Directory In Data Dire Free Rec General Set Max Vide	Setting Security About formation ctory ording Space tings o File Size	You must use a s Z:\IPCamera 54095 50	MB	Browse
	General Options General E-Mail : Directory In Data Dire Free Rec General Set Max Vide Scan Tim	Setting Security About formation ctory ording Space tings o File Size e	You must use a s Z:\IPCamera 54095 50 3 •	MB second(s)	Browse
	General Options General E-Mail : Directory In Data Dire Free Rec General Set Max Vide Scan Tim Cycle Re	Setting Security About formation ctory ording Space tings o File Size e cording	You must use a s Z:\IPCamera 54095 50 3 • Disable	MB second(s)	Browse
	General Options General E-Mail : Directory In Data Dire Free Rec General Set Max Vde Scan Tirr Cycle Re	Setting Security About formation ctory ording Space tings o File Size e cording	You must use a s Z:\IPCamera 54095 50 3 • Disable	MB second(s)	Browse
	General Options General E-Mail : Directory In Data Dire Free Rec General Set Max Vide Scan Tim Cycle Re	Setting Security About formation ctory ording Space tings o File Size e cording	You must use a s Z:\JPCamera 54095 50 3 v Disable	MB second(s)	Browse
	General Options General E-Mail Directory In Data Dire Free Rec General Set Max Vide Scan Tim Cycle Re	Setting Security About formation ctory ording Space tings o File Size e cording	You must use a s Z:\IPCamera 54095 50 3 • Disable	MB second(s)	Browse
OK Cancel	General Options General E-Mail : Directory In Data Dire Free Rec General Set Max Vide Scan Tirr Cycle Re	Setting Security About formation ctory ording Space tings o File Size e cording	You must use a s Z:\IPCamera 54095 50 3 • Disable	MB second(s)	Browse

Step 5: After you click on OK to close the General Options, you can click on Recording to record videos.

The camera displays 'Rec' for recording. Click on Recording button again to stop recording.



Step 6. Verify your NAS for the recorded video.

